
	Work Instruction	
	<h1>Reflective Coating Application</h1>	
Revision: 00	Procedure No.: WI-8.2.4.47	Date Effective: 6/11/2012

1. Prepare surface as required so coating will adhere to surface
2. Mask off, as necessary, any areas that need to be free of coating
3. Use appropriate equipment to reduce overspray and associated vapors
4. Spray, brush, or otherwise apply coating to surface with even thickness
5. Remove masking once coating has dried
6. Cure coating according to manufacturer's specifications.

## Revision History

Revision Level	Date of Revision	Sections	Description of Change	Initial
00	6/11/2012	All	Initial Release	TCH

## Authorization

Position	Held By	Signature
Product Manager	Thomas Hittie	
Senior Management Representative	Abraham Joseph	